

INSTALLATION REQUIREMENTS SBS ANDIS 1100

- Always wear personal protective equipment.
- Use the supplied parts list to check if the kit contains all the parts.
- Thoroughly clean the surface before installation.
- The product may only be installed by trained personnel.

If you have to drill or grind:

- Always wear the correct eye and hearing protection.
- Remove all material swarf before installation.
- Do not use compressed air to remove swarf, as this can cause injuries.

Contents of the box

1x Rubber lock housing with red reflective tape and Abloy cylinder.

Prevent against the theft of your trailer with this SBS Andis 1100 trailer lock.

Maintenance

- Use a cloth with WD-40 to clean the outside. This liquid prevents the adhesion of dirt and grease.
- Spray WD-40 into the cylinder once a month and allow the lock to drain on its head or side.
- Never use force to turn the key.

Severe contamination

- First remove the excess grease and dirt using a spatula.
- Clean the outside using a brush immersed in degreaser. Never immerse the entire lock in degreaser as floating dirt will still end up in the cylinder and the reflective tape may get dissolved.
- If the lock housing needs to be immersed, remove the cylinder first!
- Only clean the cylinder with WD-40 or Brunox Turbo Spray. After cleaning, drain well, dry and assemble with new adhesive.

Dismantling of cylinder

- Place the lock on its head and remove the white plastic cap.
- Unscrew the socket screw in the centre.
- Remove the socket screw, the washer and the u-shaped disc.
- Slide the lock siphon outwards and remove it.
- Use a hammer shank to push the cylinder out.
- After cleaning, always check that the lock is working properly before mounting it on a trailer.

